
HONDA

GENERATOR OWNER'S MANUAL EZ6500CXS



Dear Customer:

We carefully manufactured to give you a dependable operation.

However, similar to all mechanical products, your machine will occasionally require adjustments and maintenance. This manual should be read carefully before operating or performing any adjustments on your machine. Please contact Honda dealer if technical assistance is required.

Please be advised that unit was designed / manufactured for specific applications. So please do not modify and use the unit for any application other than which it was designed for. If you have any questions regarding any applications, please ask Honda dealer before using.

Please read an Owner's manual before use.

Safety Messages

Your safety and the safety of others are very important. We have provided important safety messages in this manual and on the generator. Please read these messages carefully.

Safety message alerts you to potential hazards that could hurt you or others. Each safety message is preceded by a safety alert symbol and one of three words; **DANGER**, **WARNING**, or **CAUTION**.

These words mean:

▲ DANGER You will be killed or seriously hurt if you don't follow instructions.
 ▲ WARNING You can be killed or seriously hurt if you don't follow instructions.
 ▲ CAUTION You can be hurt if you don't follow instructions.

Each message tells you what the hazard is, what can happen, and what you can do to avoid or reduce injury.

NOTICE

This word means:

NOTICE Your generator or other property could be damaged if you don't follow instructions.

The purpose of these messages is to help prevent damage to your generator, other property, or the environment.

Table of Contents


| 1. | SAFETY LABEL LOCATION | 3 |
|-----|------------------------------|----|
| 2. | IMPORTANT SAFETY INFORMATION | 5 |
| 3. | COMPONENTS | 7 |
| 4. | CONTROLS | 11 |
| 5. | BEFORE STARTING ENGINE | 14 |
| 6. | OPERATION | 15 |
| 7. | STOPPING ENGINE | 18 |
| 8. | MAINTENANCE | 19 |
| 9. | TRANSPORTING AND STORAGE | 25 |
| 10. | WATTAGE INFORMATION | 27 |
| 11. | TROUBLE SHOOTING | 28 |
| 12. | SPECIFICATION | 30 |
| 13. | WIRING DIAGRAM | 31 |
| | APPENDIX | |

- 1. LOOSE PARTS
- 2. INSTALLATION OF BATTERY
- 3. INSTALLATION OF WHEEL KIT

1.SAFETY LABEL LOCATION

These labels warn you of potential hazards that can cause serious injury. Read them carefully.

If a label comes off or becomes hard to read, contact your Honda dealer for a replacement.





 Honda generator is designed to give safe and dependable service if operated according to instructions.

Read and understand the Owner's Manual before operating the generator. Failure to do so could result in personal

Failure to do so could result in personal injury or equipment damage.



 Exhaust contains poisonous carbon monoxide, a colorless, odorless gas.
 Breathing carbon monoxide can cause loss of consciousness and may lead to death.

- If you run the generator in an area that is confined, or even partially enclosed area, the air you breathe could contain a dangerous amount of exhaust gas.
- Never run your generator inside a garage, house or near open windows or doors.



Gasoline is highly flammable and explosive.
 Turn the engine off and let it cool before refueling.



 Improper connections to a building's electrical system can allow current from the generator to backfeed into the utility lines.
 Such backfeed may electrocute utility company workers or others who contact the lines during a power outage, and the generator may explode, burn or cause fires when utility power is restored.
 Consult the utility company or a qualified electrician prior to making any power connections.

2. IMPORTANT SAFETY INFORMATION

Honda generators are designed for use with electrical equipment that has suitable power requirements.

Other uses can result in injury to the operator or damage to the generator and other property.

Most injuries or property damage can be prevented if you follow all instructions in this manual and on the generator. The most common hazards are discussed below, along with the best way to protect yourself and others.

- Never attempt to modify the generator.
 - It can cause an accident as well as damage to the generator and appliances.
- Do not connect an extension to the muffler.
- Do not modify the intake system.
- Do not adjust the governor.
- Do not remove the control panel or do not change the wiring of the control panel.

Operator Responsibility

- Know how to stop the generator quickly in case of emergency.
- Understand the use of all generator controls, output receptacles, and connections.
- Be sure that anyone who operates the generator receives proper instruction. Do not let children operate the generator without parental supervision.
- Be sure to observe the instructions in this manual for how to use the generator and maintenance information. Ignoring or improperly following the instructions can cause an accident such as an electric shock, and the condition of the exhaust gas may deteriorate.
- Obey all applicable laws and regulations where the generator is used.
- Gasoline and Oil is toxic.
 - Follow the instructions provided by each manufacturer before use.
- Place the generator on a firm level place before operation.
- Do not operate the generator with any cover removed. You may get your hand or foot caught in the generator and it may cause accident.
- Consult your authorized Honda dealer for disassembly and service of the generator that are not covered in this manual.

Carbon Monoxide Hazards

A generator's exhaust contains toxic carbon monoxide, which you cannot see or smell. Breathing carbon monoxide can KILL YOU IN MINUTES.

To avoid carbon monoxide poisoning, follow these instructions when operating a generator:

- Only run a generator OUTSIDE, far away from windows, doors, and vents.
- Never operate a generator inside a house, garage, basement, crawl space, or any enclosed or partially enclosed space.
- Never operate a generator near open doors or windows.
- Get fresh air and seek medical attention immediately if you suspect you have inhaled carbon monoxide.

Early symptoms of carbon monoxide exposure include headache, fatigue, shortness of breath, nausea, and dizziness. Continued exposure to carbon monoxide can cause loss of muscular coordination, loss of consciousness, and then death.

Electric Shock Hazards

The generator produces enough electric power to cause a serious shock or electrocution if misused.

- Do not use in wet conditions. Keep the generator dry.
- Do not use in the rain or snow.
- Do not use near a pool or a sprinkler system.
- Do not use when your hands are wet.
- If the generator is stored outdoors, unprotected from the weather, all of the electrical components on the control panel before each use. Moisture or ice can cause a malfunction or short circuit in electrical components that could result in electrocution.
- Do not connect to a building's electrical system unless an isolation switch has been installed by a qualified electrician.

Fire and Burn Hazards

Do not use the generator in areas with a high risk of fire.

The exhaust system gets hot enough to ignite some materials.

- Keep the generator at least 1 meter (3 feet) away from buildings and other equipment during operation.
- Do not enclose the generator in any structure.
- Keep flammable materials away from the generator.

Some parts of the internal combustion engine are hot and may cause burns. Pay attention to the warnings on the generator.

The muffler becomes very hot during operation and remains hot for a while after stopping the engine. Be careful not to touch the muffler while it is hot. Let the engine cool before storing the generator indoors.


Do not pour the water directly on the generator to put out the fire when it occurs. Use an appropriate fire extinguisher specially designed for electric fire or oil fire.

If you inhale fumes produced by an accidental fire with the generator, consult a doctor and have medical treatment immediately.


Refuel with care

Gasoline is extremely flammable, and gasoline vaper can explode.


- · Do not refuel during operation.
- Allow the engine to cool if it has been in operation.
- Refuel only outdoors in a well-ventilated area and on a level surface.
- Never smoke near gasoline, and keep other flames and sparks away.
- · Do not overfill the fuel tank.
- Make sure that any spilled fuel has been wiped up and cleaned before starting that engine.
- Always store gasoline in an approved container.




Type: R




Type: REH




Type: RK



Type: M



Type: S



4. CONTROLS

Engine switch


To start and stop the engine.

Switch position:

ON:To run the engine after starting.

OFF:To stop the engine.

START:To start the engine by turning the starter motor.



NOTICE


Return the key to the "ON" position once the engine has started.

Do not use the starter for more than 5 seconds at a time.

If the engine fails to start, release the switch and wait 10 seconds before operating the starter again.

Recoil starter

To start the engine, pull the starter grip lightly until resistance is felt, then pull briskly.



NOTICE Do not pull the starter grip from control panel side.

Starter rope may rub and be broken.


Do not allow the starter to snap back against the engine.


Return it gently to prevent damage to the starter.

Fuel valve

The fuel valve is located between the fuel tank and carburetor.

When the valve lever is in the "ON" position, fuel is allowed to flow from the fuel tank to the carburetor. Be sure to return the lever to "OFF" after stopping the engine.





ON Position


OFF Position

Choke Rod

The choke is used to provide proper starting mixture when the engine is cold.

It can be opened and closed by operating the choke lever manually.


Slide the lever toward the "CLOSED" to enrich the mixture.




Circuit Breaker

The Circuit breaker will automatically cut off the circuit if there is a short circuit or a significant overload of the generator at the receptacle.

If the circuit breaker is OFF automatically, check that the appliance is working properly and does not exceed the rated load capacity of the circuit before ON position to push the circuit breaker.





OFF position

Ground terminal

The generator ground terminal is connected to the frame of the generator, the metal non-current carrying parts of the generator, and the ground terminals of each receptacle.

Pilot lamp

The pilot lamp is illuminated when the generator is operating normally.

Oil Alert System

The Oil Alert system is designed to prevent engine damage caused by an insufficient amount of oil in the crankcase. Before the oil level in the crankcase can fall below a safe limit, the Oil Alert system will automatically stop the engine (the engine switch will remain in the ON position).

If the engine stops and will not restart, check the engine oil level (see page 14) before troubleshooting in other areas.

5. BEFORE STARTING ENGINE

⚠ CAUTION


Be sure to check the generator on a level surface with the engine stopped.

Before each use, look around and underneath the engine for signs of oil or gasoline leaks.

- 1. Fill recommended engine oil to the upper level if the oil is short.
- 2. Change oil if it becomes dirty or discolored.


Oil capacity at upper level mark: See below drawing.

Oil capacity: 1.10



3. Check the fuel level. See below drawing.

If fuel level is low, refill with unleaded automotive gasoline.



4. Fuel tank capacity: 15.50


⚠ WARNING


- Gasoline is extremely flammable and is explosive under certain conditions.
- Refuel in a well ventilated area with the engine stopped. Do not smoke or allow flames or sparks in the area where the engine is refueled or where gasoline is stored.
- Do not overfill the fuel tank (there should be no fuel above the upper limit mark).

 After refueling, make sure the fuel filler cap is closed properly and securely.
- Be careful not to spill fuel when refueling. Spilled fuel or fuel vapor may ignite. If any fuel is spilled, make sure the area is dry before starting the engine.
- Avoid repeated or prolonged contact with skin or breathing of vapor.
 KEEPOUT OF REACH OF CHILDREN.


STARTING THE ENGINE Manual start (Use the Recoil starter)

- Make sure that all electrical loads from panel receptacles are disconnected.
 The generator may be hard to start if a load is connected.
- 2) Turn the fuel valve to the "ON" position.
- If you want to start operating the choke manually, move the choke rod to the "CLOSED" position.






 Start the engine.
 Turn the engine switch to the "ON" position.



Pull the starter grip lightly until resistance is felt, then pull briskly.



NOTICE

Do not allow the starter grip to snap back against the engine. Return it gently to prevent damage to the starter or housing.


5) If you have manually closed the choke, move it to the "OPEN" position as the engine warms up.

Electric start

Take steps (1) through (3) in "MANUAL START" section.

4) Start the engine

With the electric starter:Turn the engine switch to the "START" position and hold it there until the engine starts.



NOTICE

Do not use the electric starter for more than 5 seconds at the time. If the engine fails to start, release the switch and wait 10 seconds before operating the starter again.

NOTICE

When the speed of the starter motor drops after a period of the time, it is the indication that the battery should be recharged.

- 5) After the engine starts, let the engine switch return to "ON".
- 6) If you have manually closed the choke, move it to the "OPEN" position as the engine warms up.

2. APPLYING AC LOAD

- 1) Start engine (see STARTING THE ENGINE).
- 2) Allow the engine to warm up for 2-3 minutes before connecting tools or appliances.
- 3) Insert the plug of the electrical appliance into "AC RECEPTACLE".

NOTICE

- ** Do not take a current exceeding the specified amperage.
- ** Be sure that total wattage of all appliances does not exceed the rated output of the generator.
- ** Limit length of extension cables: 60m for cables of 1.5mm² and 100m for cables of 2.5mm².


⚠ CAUTION

When the generator is overloaded or a short circuit is made, the CIRCUIT BREAKER will trip to protect the circuit automatically. If CIRCUIT BREAKER trips during operation, the generator is either over loaded or the appliance is defective.


Check the appliance and / or generator for defect or overloading and make necessary repairs or corrections before use.

7. STOPPING ENGINE

- 1) Disconnect all electrical loads from panel receptacles.
- 2) Turn the engine switch to the "OFF" position.



3) Turn the fuel valve to the "OFF" position.



⚠ CAUTION

Never leave an appliance plugged into the generator when you stop the generator as damage could result to the generator and / or appliance.

To stop the engine in an emergency, turn the engine switch to the "OFF" position.

8. MAINTENANCE

Periodic inspection and adjustment of Honda engine & Generator is essential if high-level performance is to be maintained. Regular maintenance will also ensure a long service life. The required service intervals and kind of maintenance to be performed are described on OWNER'S MANUAL.

NOTICE

Use only genuine Honda parts or their equivalent for maintenance or repair.

Replacement parts, which are not of equivalent quality, may damage the generator.

MAINTENANCE SCHEDULE

| | VISE PERIOD very indicated month or interval, whichever | Each use | First month or 20Hrs. | Every 3month or 50Hrs. (3) | Every 6month or 100Hrs. (3) | Every Year or 300Hrs . (3) | PAGE |
|------------------------|---|---|-------------------------|--|---|--|------|
| Engine oil | Check level | 0 | | | | | 14 |
| | Change | | 0 | | 0 | | 20 |
| Air cleaner | Check | 0 | | | | | - |
| | Clean | | | O (1) | | | 23 |
| Spark plug | Check-Clean | | | | 0 | | 22 |
| | Replace | | | | | 0 | - |
| Valve clearance | Check-Adjust | | | | | O (2) | - |
| Combustion Chamber | Clean | | After every 500 Hrs.(2) | | | | - |
| Fuel tank and strainer | Clean | | | | O (2) | | - |
| Fuel tube | Check | Every 2 years (2) (Replace if necessary) | | | - | | |

- (1) Service more frequently when used in dusty areas.
- (2) These items should be serviced by your dealer, unless the owner has the proper tools and is mechanically proficient. See the service manual.
- (3) For professional commercial use, log hours of operation to determine proper maintenance intervals.

Failure to follow this maintenance schedule could result in non-warrantable failures.

Engine oil


Engine oil is a major factor affecting engine performance and service life.

Non detergent oils and 2-stroke engine oils will damage the engine and are not recommended.

Check the oil level BEFORE EACH USE with the generator on a level surface with the engine stopped.

Use a high quality detergent oil classified "For Service SF,SG,SH,SJ" 4-stroke motor oil. Use no special additives with recommended oils. Do not mix oil with gasoline.


- ** Air-cooled engines run hotter than automotive engines. The use of no-synthetic multi-viscosity oils (5W-30,10W-30,etc.)in temperatures above 40° F(4°C), will result in higher than normal oil consumption. When using multi-viscosity oil, check oil level more frequently
- ** SAE30 oil, if used below 40° F (4°C), will result in hard starting and possible engine bore damage due to inadequate lubrication.



Engine oil change

Drain the oil while the engine is warm to assure rapid and complete draining.

- 1) Remove the drain plug and sealing washer, oil filler cap, and drain the oil.
- 2) Refill with the recommended oil and check the level.
- 3) Reinstall the drain plug and sealing washer. Tighten the plug securely. Sealing washer can not be reused. Replace with new.



⚠ CAUTION

Used motor oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as

soon as possible after handling used oil.

Please dispose of used motor oil in a manner that is compatible with the environment. We suggest you take it in a sealed container to your local service station or recycling center

for reclamation. Do not throw it in the trash or pour it on the ground.

Refueling

Fuel tank capacity: 15.50

Check the fuel level gauge, and refill the tank if the fuel level is low.

⚠ WARNING

Gasoline is highly flammable and explosive, and you can be burned or seriously injured when handling fuel.

· Stop engine and keep heat, sparks, and flame away.

Handle fuel only outdoors.


· Wipe up spills immediately.

Refuel in a well-ventilated area before starting the engine. If the engine has been running, allow it to cool. Refuel carefully to avoid spilling. Do not fill above the shoulder of the fuel strainer. After refueling, tighten the fuel tank cap securely.

Never refuel the generator inside a building where gasoline fumes may reach flames or sparks. Keep gasoline away from appliance pilot lights, barbecues, electric appliances, power tools, etc.

Spilled fuel is not only a fire hazard, it causes environmental damage. Wipe up spills immediately.

21



Spark plug service

Recommended spark plugs:


EZ6500CXS: W16EPR-U (DENSO), BPR5ES (NGK)

To ensure proper engine operation, the spark plug must be properly gapped and free of deposits.


If the engine has been running, the muffler will be very hot. Be careful not to touch the muffler.

PLUG WRENCH

- 1) Remove the spark plug cap.
- Clean any dirt from around the spark plug base.
- 3) Use the wrench supplied in the tool kit to remove the spark plug.
- 4) Visually inspect the spark plug. Discard it if the insulator is cracked or chipped. Clean the spark plug with a wire brush if it is to be reused.
- Measure the plug gap with a feeler gauge.
 Correct as necessary by carefully bending the side electrode.



The gap should be: 0.7mm-0.8mm



- 6) Check that the spark plug washer is in good condition, and thread the spark plug in by hand to prevent cross-threading.
- 7) After the spark plug is seated, tighten with a spark plug wrench to compress the washer.
 - If installing a new spark plug, tighten 1/2 turn after the spark plug seats to compress the washer. If reinstalling an used spark plug, tighten 1/8-1/4 turn after the spark plug seats to compress the washer.

NOTICE

The spark plug must be securely tightened. An improperly tightened spark plug can become very hot and could damage the engine.

Never use spark plugs which have an improper heat range. Use only the recommended spark plugs or equivalent.

Air cleaner service

A dirty air cleaner will restrict air flow to the carburetor. To prevent carburetor malfunction, service the air cleaner regularly. Service more frequently when operating the generator in extremely dusty areas.

⚠ WARNING

Using gasoline or flammable solvent to clean the filter element can cause a fire or explosion. Use only soapy water or nonflammable solvent.


NOTICE

Never run the generator without the air cleaner. Rapid engine wear will result.

- Unsnap the air cleaner cover clips, remove the air cleaner cover, and remove the element.
- Wash the element in a solution of household detergent and warm water, then rinse thoroughly; or wash in nonflammable or high flash point solvent. Allow the element to dry thoroughly.
- Soak the element in clean engine oil and squeeze out the excess oil.
 The engine will smoke during initial start-up if too much oil is left in the element.
- Reinstall the air cleaner element and the cover.

CLIP AIR CLEANER COVER

AIR CLEANER ELEMENT





Fuel sediment cup cleaning

The sediment cup prevents dirt or water which may be in the fuel tank from entering the carburetor. If the engine has not been run for a long time, the sediment cup should be cleaned.

- Turn the fuel valve to the "OFF" position. Remove the sediment cup, O-ring, and filter.
- Clean the sediment cup, O-ring, and filter in nonflammable or high flash point solvent.
- Reinstall the filter, O-ring, and sediment cup. O-ring can not be reused. Replace with new.
- Turn the fuel valve "ON" and check for leaks.







9. TRANSPORTING AND STORAGE

When transporting the generator, turn the engine switch and the fuel valve "OFF". Keep the generator level to prevent fuel spillage. Fuel vapor or spilled fuel may ignite.

⚠ WARNING

Touch a hot engine or exhaust system can cause serious burns or fires. Let the engine cool before transporting or storing the generator.

Take care not to drop or strike the generator when transporting. Do not place heavy objects on the generator.

Before storing the unit for an extended period:


- 1) Be sure the storage area is free of excessive humidity and dust.
- Be sure remove the battery.
 See APPENDIX 2.INSTALLATION OF BATTERY
- 3) Service according to the table below:

| STORAGE TIME | RECOMMENDED SERVICE PROCEDURE TO PREVENT HARD STARTING |
|--------------------|---|
| Less than 1 month | No preparation required. |
| 1 to 2 months | Fill with fresh gasoline and add gasoline conditioner*. |
| 2 months to 1 year | Fill with fresh gasoline and add gasoline conditioner*. Drain the carburetor float bowl. Drain the fuel sediment cup. |
| 1 year or more | Fill with fresh gasoline and add gasoline conditioner*. Drain the carburetor float bowl. Drain the fuel sediment cup. Remove the spark plug. Put a tablespoon of engine oil into the cylinder. Turn the engine slowly with the pull rope to distribute the oil. Reinstall the spark plug. Change the engine oil. After removal from storage, drain the stored gasoline into a suitable container, and fill with fresh gasoline before starting. |

1) Drain the carburetor by loosening the drain screw. Drain the gasoline into a suitable container.

⚠ WARNING

Gasoline is extremely flammable and is explosive under certain conditions. Perform this task in a well ventilated area with the engine stopped. Do not smoke or allow flames or sparks in the area during this procedure.



- 2) Change the engine oil.
- 3) Remove the spark plug, and pour about a tablespoon of clean engine oil into the cylinder. Crank the engine several revolutions to distribute the oil, then reinstall the spark plug.
- 4) Slowly pull the starter grip until resistance is felt. At this point, the piston is coming up on its compression stroke and both the intake and exhaust valves are closed. Storing the engine in this position will help to protect it from internal corrosion.

10. WATTAGE INFORMATION

Some appliance needs a "surge" of energy at starting. This means that the amount of electrical power needed to start the appliance may exceed the amount needed to maintain its use. See the chart below for appliances you may use with this generator.

Electrical appliance and tools normally come with a label indicating voltage, cycles/ Hz, amperage and electrical power needed to run the appliance or tool. If no specification label is found, check with your nearest dealer for the power surge of your appliances or power tools.

NOTICE

The following wattage chart is guidance only.


Refer to your specific appliance for correct wattage.

APPLICABLE WATTAGE (W)


| MODEL | EZ6500CXS | | |
|------------------------------|-----------|------|--|
| APPLIANCE | 50Hz | 60Hz | |
| INCANDESCENT LAMP, HEATER | 5000 | 5500 | |
| FLUORESCENT LAMP, | 3000 | 3200 | |
| MARCURY LAMP | 2400 | 2600 | |
| ELECTRIC TOOLS | 3000 | 3200 | |
| PUMP, COMPRESSOR | 1200 | 1500 | |

11. TROUBLE SHOOTING


When the engine will not start:



No electricity at the A.C RECEPTACLES:



Starter motor does not turn round:



^{***}If your generator still fails to start or generate electricity, contact Honda dealer.

12. SPECIFICATION

| MODEL | | EZ6500CXS | | | | | | |
|----------------------|----------------|-----------------|-------------------|---------------|------------|-----------|--|--|
| ★ENGINE | | | | | | | | |
| Model | | | Honda GX390 | | | | | |
| Displaceme | ent | cm ³ | | 389 | | | | |
| Oil alert sys | stem | | | YE | S | | | |
| Starting Sys | stem | | Recoil & Electric | | | | | |
| Oil Capacity | у | ł | 1.1 | | | | | |
| ★ GENERATO | OR | | | | | | | |
| System | | | Self-exc | iting, 2pole, | field rota | ting type | | |
| Voltage reg | ulation system | | | AV | R | | | |
| Phase | | | | Sing | gle | | | |
| Rated power | er factor | $\cos\phi$ | | 1.0 | כ | | | |
| Insulation C | Class | | | F | | | | |
| TYPE | | | R | REH | RK | М | | |
| Rated Volta | ige | V | 220 2 | | 230 | | | |
| Frequency | | Hz | 50 | | | | | |
| AC | Rated | kW | 5.0 | | | | | |
| Output | Maximum | kW | | 5.5 | 5 | | | |
| | | | | | | | | |
| TYPE | | _ | | S | | | | |
| Rated Volta | ige | V | 220 | | | | | |
| Frequency | | Hz | 60 | | | | | |
| AC | Rated | kW | 5.5 | | | | | |
| Output | kW | 6.5 | | | | | | |
| ★ OTHERS | | | | | | | | |
| Fuel Tank Capacity | | ł | 15.5 | | | | | |
| Length | | mm | 690 (690) | | | | | |
| Size | Width | mm | 535 (670) | | | | | |
| | Height | mm | 540 (610) | | | | | |
| Continuous operating | | Hr | 50Hz 5.8 | | | | | |
| Continuous | - operating | 1 " | 60Hz 5.4 | | | | | |

Specifications are subject to change without notice.


Dry Weight

() with wheel kit


0.08

kg


13. WIRING DIAGRAM




Type: REH



Type: RK



Type : M



APPENDIX

- 1. LOOSE PARTS
- 2. INSTALLATION OF BATTERY
- 3. INSTALLATION OF WHEEL KIT


1. LOOSE PARTS

Check all loose parts against the following list.

Contact your dealer if any of the loose parts shown below are not included with your generator.


Type: R, S

| Ref. No. | Description | Qty. |
|----------|-------------------|------|
| 1 | PLUG | 2 |
| 2 | PLUG WRENCH | 1 |
| 3 | SHAFT | 2 |
| 4 | WHEEL | 2 |
| 5 | WASHER | 2 |
| 6 | COVER | 2 |
| 7 | FLANGE BOLT M8-16 | 4 |
| 8 | FLANGE NUT M8 | 4 |
| 9 | STAND | 2 |
| 10 | SNAP PIN | 2 |
| 11 | KEY | 1 |
| 12 | PLATE , BATTERY | 1 |
| 13 | FLANGE BOLT M6-12 | 2 |
| - | OWNER'S MANUAL | 1 |




Type: REH

| Ref. No. | Description | Qty. |
|----------|-------------------|------|
| 1 | PLUG | 2 |
| 2 | PLUG WRENCH | 1 |
| 3 | SHAFT | 2 |
| 4 | WHEEL | 2 |
| 5 | WASHER | 2 |
| 6 | COVER | 2 |
| 7 | FLANGE BOLT M8-16 | 4 |
| 8 | FLANGE NUT M8 | 4 |
| 9 | STAND | 2 |
| 10 | SNAP PIN | 2 |
| 11 | KEY | 1 |
| 12 | PLATE , BATTERY | 1 |
| 13 | FLANGE BOLT M6-12 | 2 |
| - | OWNER'S MANUAL | 1 |




Type : RK

| Ref. No. | Description | Qty. |
|----------|-------------------|------|
| 1 | PLUG | 2 |
| 2 | PLUG WRENCH | 1 |
| 3 | SHAFT | 2 |
| 4 | WHEEL | 2 |
| 5 | WASHER | 2 |
| 6 | COVER | 2 |
| 7 | FLANGE BOLT M8-16 | 4 |
| 8 | FLANGE NUT M8 | 4 |
| 9 | STAND | 2 |
| 10 | SNAP PIN | 2 |
| 11 | KEY | 1 |
| 12 | PLATE , BATTERY | 1 |
| 13 | FLANGE BOLT M6-12 | 2 |
| - | OWNER'S MANUAL | 1 |



Type : M

| Ref. No. | Description | Qty. |
|----------|-------------------|------|
| 1 | PLUG | 2 |
| 2 | PLUG WRENCH | 1 |
| 3 | SHAFT | 2 |
| 4 | WHEEL | 2 |
| 5 | WASHER | 2 |
| 6 | COVER | 2 |
| 7 | FLANGE BOLT M8-16 | 4 |
| 8 | FLANGE NUT M8 | 4 |
| 9 | STAND | 2 |
| 10 | SNAP PIN | 2 |
| 11 | KEY | 1 |
| 12 | PLATE , BATTERY | 1 |
| 13 | FLANGE BOLT M6-12 | 2 |
| - | OWNER'S MANUAL | 1 |



2. INSTALLATION OF BATTERY

⚠ WARNING

- Batteries produce explosive gases: If ignited, and explosion can cause serious injury or blindness. Provide adequate ventilation when charging.
- CHEMICAL HAZARD: battery electrolyte contains sulfuric acid.
 Contact with eyes or skins, even through clothing, may cause severe burns. Wear

a face shield and protective clothing.

Keep flames and sparks away, and do not smoke in the area.

- ANTIDOTE: If electrolyte gets into your eyes, flush thoroughly with warm water for at least 15 minutes and call a physician immediately.
- POISON: Electrolyte is poison.

ANTIDOTE


- External: flush thoroughly with water.
- Internal: drink large quantities of water of milk.

Follow with milk of magnesia or vegetable oil, and call a physician immediately. KEEP OUT OF REACH OF CHILDREN.

Recommended battery : 12V-12Ah $\,\sim\,$ 12V-17Ah

INSTALLATION

- 1. Connect the battery positive (+) cable to the battery positive (+) terminal first, and tighten the bolt securely.
- 2. Slide the battery boot over the positive (+) cable and terminal.
- 3. Connect the battery negative (-) cable to the battery negative (-) terminal, and tighten the bolt securely.
- 4. Slide the battery boot over the negative (-) cable and terminal.



5. Install the battery. Install battery plate using two M6-12mm flange bolts.

TORQUE: 8.0 - 12.0 N·m

REMOVAL

- 1. Remove the battery plate.
- 2. Remove the negative (-) cable from the battery negative (-) terminal, and then remove the positive (+) cable from the battery.

⚠ CAUTION

When disconnecting the battery cable, be sure to disconnect at the battery negative (-) terminal first. To connect at the positive (+) terminal first, then at the negative (-) terminal. Never dis/ connect the battery cable in the reverse order, or it causes a short circuit when a tool contacts the terminals.

↑ WARNING

The battery gives off explosive gasses; keep sparks, flames, and cigarettes away from the battery while charging. Provide adequate ventilation when charging.

- The battery contains sulfuric acid (electrolyte). Contact with skin or eyes may cause service burns. Wear protective clothing and a face shield.
 - If electrolyte gets on your skin, flush with water.
 - If electrolyte gets in your eyes, flush with water for at least 15 minutes and call a physician immediately.
- Electrolyte is poisonous.
 - If swallowed, drink large quantities of water or milk and follow with milk of magnesia or vegetable oil and call a physician.
- 1. Connect the battery charger following the manufacturer's instructions.
- 2. Charge the battery 5 10 hours.
- 3. Clean the outside of the battery and the battery tray compartment with a solution of baking soda and water.



This symbol on the battery means that this product must not a treated as household waste.

NOTICE


An improperly disposed of batter can be harmful to the environment and human health. Always confirm local regulations for battery disposal.

3. INSTALLATION OF WHEEL KIT

1. Install the two stands on the under frame using M8-16mm flange bolts and M8 nuts.

TORQUE: 20.0 - 24.0 N·m

- 2. Install wheels on the side of frame bracket with shaft and cover.
- 3. Fix each shaft with a snap pin and washer.



EZ6500CXS OWNER'S MANUAL